



Footrest kit "FACTORY" Yamaha YZF 600, R6, from year 2003 → (cod.756F)

1



Thank you for purchasing the PP rear set. Please pay attention to several assembling advices, those will prolong the product life and will guarantee the correct working of it.

The essential difference of our set is that the shift rod is led outside the frame.
By assembling the footrest kit – dismount the stock shift lever and see fotos 1 – 9 as following.



1

Loose the nut and pull out the bolt on the left side of the bike.



2



3

Put in the same bolt from the right side of the bike and be assured it goes through to the left side.



4



5

Put the spacer supplied in PP Tuning kit on the thread which is sticking out and tighten up.



6

Footrest kit "FACTORY"
Yamaha YZF 600, R6, from year 2003 →
(cod.756F)

2



7



8

Assemble with
the shifter

The shift shaft joint is needed to be dismantled and turned
around (pictures A,B,C)
That adaptation is required because of lack of space for shift rod.



A

before



B



C

after



9

WARNING

Our rear set is specified for race tracks only. Can not be used in
a common traffic due to brake light disfunction.
The product is not certified for a road traffic.



PP Tuning s.r.o.

Trbousanska 31, Dolni Kounice - 664 64, okr.Brno - venkov, Czech Republic
email: pptuning@volny.cz, tel:00420 603 362 701, fax: 00420 546 421 593