



## Installation instructions for Brake lever Can-Am

### Part Nr. 2009

We would like to thank you for purchasing PP Tuning Brake lever. Please take a moment to read the assembly instructions. Following these instructions will ensure trouble free operation of this product and extend its working life.

- 1) Remove the original brake lever including the handbrake.
- 2) From the original brake lever use the pin + spring + lock washer.
- 3) Use these original parts to mount the PP brake lever.

