

Installation instructions for Rear Set Honda CBR 600RR (2024-) Part Nr. 7371

Left side installation

Remove the original (OEM) rearset. The shift lever is mounted instead the left screw on the side stand (marked with an arrow in pic. 1). Screw a spacer into the place Nr. 82551 (marked with an arrow in pic. 2). On this spacer mounted the shift lever (pic. 2-4).



Right side installation

The right side is mounted in the same way as the original (OEM) rearset as shown in pic. 4.

If you want to keep function of the brake light sensor, we recommend to buy a brake sensor (part Nr. BC125).